

### **Compack Controller**

### Monitoring and Control Unit

#### SMALL WITH ALL

"All-in-one" plug-in controller. Comprehensive functionality in a small box designed for small range power systems.



## **COMPACK CONTROLLER**

Doc 242100.400.DS3 - v6

#### APPLICABLE SYSTEMS

#### **TELECOM**

- CHAMELEON
- MICROPACK 48V
- MINIPACK 1U
- PLATPACK2 DC/DC IN INTERFACE

#### **INDUSTRIAL**

- MICROPACK 12V & 24V
- COMPACK INTERFACE KIT



MINIPACK 1U 1600W SYSTEM



MICROPACK 1000W CONVECTION COOLED SYSTEM



COMPACK IN INTERFACE KIT (PN 242100.900)



COMPACK IN CHAMELEON SYSTEM

### **KEY FEATURES**

- REMOTE MONITORING VIA ETHERNET
  - SNMP (v3,v2c,v1)
  - **WEB PAGES**
  - EMAIL OF LOGS AND ALARMS
- 3 CONFIGURABLE RELAYS
- 3 MULTIPURPOSE INPUTS
  - **TEMPERATURE**
  - **SYMMETRY**
  - **DIGITAL INPUT**
- 2 LVD CONTROLLS (LVBD+LVLD)
- 12V,24V,30V,48V & 60V SUPPORTED
- **BATTERY MONITORING** 
  - AUTO/PERIODIC TEST
  - CAPACITY/QUALITY ESTIMATION
- **ELTEK SOFTWARE SUPPORTED** 
  - **ELTEK NETWORK UTILITY**
  - MULTISITE MONITOR
  - **POWER SUITE**

# **COMPACK CONTROLLER**



FOR 12V, 24V, 30V, 48V & 60V SYSTEMS

ELECTRICAL SPECIFICATIONS		
Input Voltage	9 - 75 V <sub>DC</sub> , shutdown < 8.5 V <sub>DC</sub> *	
Temperature Range	Nominal: -20 to +60 C (-4 to 140 F) Reduced accuracy: -40 to +70 C	
Power Consumption	3W	
MTBF	> 550, 000 hours Telcordia SR-332 Issue I, method III (a) (Tambient : 25°C)	
Ethernet port	10/100 BASE-T HP Auto MDI/MDI-X	
Relay Outputs (1,5 mm2)	Form-C (dry contact NO-C-NC), Max 75V/2A/60W breaking capacity	
Configurable Inputs (1,5 mm2)	Temperature: External NTC, "Digital": open/closed,	Analog: 0-75V, Battery Symmetry: 0-75V
CONTROL FEATURES		
Control System	<ul> <li>Output Voltage Measurement</li> <li>Load Current Calculation</li> <li>Energy Calculation</li> <li>Load/Battery Disconnect</li> <li>Real Time Clock with Battery Backup</li> <li>Stored Site Text/ID and Messages</li> </ul>	<ul> <li>o Output Voltage Measuremento Position (long/lat) for auto placement</li> <li>o Generator start/stop control setup</li> <li>o Test of Relay Outputs</li> <li>o Alarm grouping of events for relay outputs</li> <li>o Boolean AND of alarm groups</li> </ul>
Battery	o Battery Current Measurement o Battery Temperature Measurement Battery Testing (acc. to discharge table or set time limit) o Setup of Battery Data/Table o Battery Capacity Indication o Battery Boost Charging - Auto – Ah discharge or voltage threshold - Interval or Manual	o Temperature Compensated Charging o Charge Current Limitation o Battery Low Voltage Disconnect - Temperature dependent (optional) - Mains independent (optional)
Rectifier	<ul> <li>Available information about each rectifier,</li> <li>e.g. serial number, version, internal</li> <li>temperature</li> <li>Individual Rectifier Current Measurement</li> <li>Individual Rectifier Input Voltage</li> </ul>	<ul> <li>Energy calculation</li> <li>Efficiency Management</li> <li>Emergency Voltage</li> <li>Startup delay</li> <li>Detailed internal alarms summary</li> </ul>
ALARMS / EVENTS AVAILABLE		
Alarms can be set up with monitorin analogue values are auto logged.	g of minor and major levels. Hysteresis and time delay is use	er configurable. All average and peak levels on
Power & Control System	<ul> <li>o AC Mains Low (2-level)</li> <li>o AC Phase Voltage x3 (2-level)</li> <li>o "Digital" Inputs (programmable descriptions)</li> <li>o Events trigger by inputs</li> </ul>	<ul> <li>Service mode (block relays), Generator runnin Lower charge current limit, Battery test, Boo- Inhibit, Emergency low voltage, Clear manual reset alarms.</li> </ul>
Load	<ul> <li>Load Disconnect</li> <li>Voltage or Timer (from mains failure) based</li> <li>Mains independent (optional)</li> </ul>	o Load Fuse o Load Current
Battery	o Battery Voltage (4-level, optional 8-level) o Battery Temperature (2-level) o Battery Used Capacity (2-level) [Ah or %] o Battery Remaining Capacity (2-level) [Ah or %] o Battery Fuse	o Symmetry Failure (2-level) o Battery Quality after test (2-level) o Battery Current (4-level) o Battery Life Time (2-level) [from temperature log]
	o Rectifier Failure (2-level) o Rectifier Capacity (2-level)	o Rectifier Avg. Temperature (2-level)
Rectifier/Converter	o Rectifier Carpacity (2-level)	o Rectifier Current Share (2-level)
DATA LOGGING		o Rectifier Current Share (2-level)
DATA LOGGING Control System	o Rectifier Current (2-level)	o Rectifier Current Share (2-level) s), Configuration Change log, Account Access log
DATA LOGGING Control System Energy	o Rectifier Current (2-level)  Event log, Data log (configurable up to 20 monitors  Energy delivered from Rectifiers, Solar Charger and	o Rectifier Current Share (2-level) s), Configuration Change log, Account Access log l Battery, and consumed energy by the load for the
DATA LOGGING Control System Energy Battery	o Rectifier Current (2-level)  Event log, Data log (configurable up to 20 monitors  Energy delivered from Rectifiers, Solar Charger and last 52 hours, 52 days and 52 weeks	o Rectifier Current Share (2-level) s), Configuration Change log, Account Access log l Battery, and consumed energy by the load for the ycles for the last 52 hours, 52 days and 52 weeks
DATA LOGGING Control System Energy Battery Generator	o Rectifier Current (2-level)  Event log, Data log (configurable up to 20 monitors  Energy delivered from Rectifiers, Solar Charger and last 52 hours, 52 days and 52 weeks  10 last battery tests detailed, number of battery of Run time in minutes and fuel consumption for the last	o Rectifier Current Share (2-level) s), Configuration Change log, Account Access log d Battery, and consumed energy by the load for the ycles for the last 52 hours, 52 days and 52 weeks ast 52 hours, 52 days and 52 weeks
DATA LOGGING Control System Energy Battery Generator Model	o Rectifier Current (2-level)  Event log, Data log (configurable up to 20 monitors  Energy delivered from Rectifiers, Solar Charger and last 52 hours, 52 days and 52 weeks  10 last battery tests detailed, number of battery c	o Rectifier Current Share (2-level) s), Configuration Change log, Account Access log l Battery, and consumed energy by the load for the ycles for the last 52 hours, 52 days and 52 weeks
Rectifier/Converter  DATA LOGGING Control System Energy Battery Generator  Model Part number  Dimensions (HxWxD)	o Rectifier Current (2-level)  Event log, Data log (configurable up to 20 monitors  Energy delivered from Rectifiers, Solar Charger and last 52 hours, 52 days and 52 weeks  10 last battery tests detailed, number of battery c  Run time in minutes and fuel consumption for the lacence of the second compacts.	o Rectifier Current Share (2-level)  s), Configuration Change log, Account Access log Battery, and consumed energy by the load for the ycles for the last 52 hours, 52 days and 52 weeks ast 52 hours, 52 days and 52 weeks  Compack Interface Kit

Doc 242100.400.DS3 - v6

Specifications are subject to change without notice